

REPAIR INSTRUCTIONS

ENAMEL-SET.

- The surface to be repaired must be clean, dry, free of oil and grease. Any rust should be removed via the use of a steelbrush (if there is a strong rust build-up, use a rust remover).
- The damaged area should then be cleaned with a dust-free cloth and oil-free cleanser (acetone, etc.) let it dry (evaporate) for a few minutes.
- Mix the required amount of filler at a ratio of 30:1 with the hardener, use the spatula to smooth the filler compound into the damaged area and allow the repair to dry for approximately 30 minutes.
- After that use the sandpaper to give an even smoother finish and wipe the area clean.
- Next, prepare the enamel spray by shaking the can vigorously for 3 minutes. Test the spray to ensure that a fine mist comes from the nozzle. (A minimum temperature of 20° C for spraying is required).
- Spray from a distance of 15-20 cm, applying a light coat of spray. After approximately 1 minute, apply another coat. Repeat as often as necessary until the desired coverage is reached.
- In case the spray is applied too thick and runs (forms drops), remove excess with the cleaner. Repeat the spraying after the surface has dried.
- On vitreous china, broken pieces can be re-attached with the compound (glued). For the rest of the finishing process - follow above instructions.

IMPORTANT:

Afterward, the repair surface should not be cleaned or exposed to water for 4 days so that the repair can harden 100%.

- Please pay attention to the written notices on each of the components of the Repair Kit items.

WARNING : DO NOT STORE IN TEMPERATURES OVER 30° C.